

Note

Thank you very much for purchasing this Standard Horizon product. Local Channel assignments are not set in the factory. Before using the transceiver for the first time please set the local channel assignment as below.

Caution: If you do not set the Region number, you will not be able to select a specific channel.

To do this, follow the procedure below:

1. Please confirm the region number to use the radio (see table below).

Region	Display	Additional Channel
INTERNATIONAL	INT	--
UNITED KINGDOM	UK	M: 157.850 MHz (TX/RX) M2: 161.425 MHz (TX/RX)
BELGIUM	BE	CH31: 157.550 MHz (TX) / 162.150 MHz (RX)
NETHERLANDS	NL	CH31: 157.550 MHz (TX) / 162.150 MHz (RX) CH37: 157.850 MHz (TX/RX)
SWEDEN	SW	L1: 155.500 MHz (TX/RX) L2: 155.525 MHz (TX/RX) L3: 155.650 MHz (TX/RX) F1: 155.625 MHz (TX/RX) F2: 155.775 MHz (TX/RX) F3: 155.825 MHz (TX/RX)
GERMANY	GRM	--

2. Turn the transceiver OFF.
3. Press and hold in the [16/S] and [MENU] keys on the front panel while turning the transceiver ON.
The region selection screen appears on the display.
4. Press the [▲] or [▼] key momentarily to select the desired region (see table above).
5. Press the [ENTER] soft key to store the selected setting.
A "Selected" will appear in the display.
6. Press the [OK] soft key to restart automatically.
Setting of region was successfully completed.

Note: After a factory reset, any local channel assignments will be lost and this procedure will need to be repeated.



STANDARD HORIZON

